

ETC® Setup Guide

Congo™ Light Server



Congratulations on your purchase of the ETC® Congo™ Light Server. The Congo Light Server may be configured to run the Congo application software as a server, backup, or client in a Congo and Congo jr console system.

- When the unit is configured as a server, it is the master and maintains the show file and controls output to the lighting system.
- When the unit is configured as a backup, the unit will perform synchronized backup with a server and will take control of the lighting system upon the loss of communication with the server.
- When the unit is configured as a client, you can access real time inputs and outputs of the lighting system through the server.

This document will guide you in the setup and simple operation of the Congo Light Server for use with the Congo and Congo jr control systems. For information on integrating the Congo Light Server with your Congo or Congo jr console, please refer to the Congo/Congo jr Operations Manual that shipped with your console or you may download it from our website at www.etconnect.com.

Check Shipping Contents

Check the shipping carton to ensure all contents have arrived and are undamaged. Your Light Server ships with the following items:

- USB Mouse
- DVI (male) to VGA (female) adaptor (x2)
- Congo/Congo jr User Manual (on CD)
- IEC Power cords with International connector selection
- USB Keyboard
- Dual DVI video Y-adaptor
- 19" Rack Mount Kit

Electrical and Environmental Specification

- Operating temperature - 100-240VAC, 50-60Hz (2 amps at 120 VAC)
- Ambient temperature and humidity - 0 to 40 degrees C, 95% non-condensing humidity maximum
- Storage temperature and humidity - 0 to 40 degrees C, 95% non-condensing humidity
- CE and ETL Compliant
- Installation Category II, Indoor use only
- Pollution degree 2
- May operate up to 2000 meters altitude




Corporate Headquarters ■ 3031 Pleasant View Road, P.O. Box 620979, Middleton, Wisconsin 53562-0979 USA ■ Tel +608 831 4116 ■ Fax +608 836 1736
London, UK ■ Unit 26-28, Victoria Industrial Estate, Victoria Road, London W3 6UU, UK ■ Tel +44 (0)20 8896 1000 ■ Fax +44 (0)20 8896 2000
Rome, IT ■ Via Ennio Quirino Visconti, 11, 00193 Rome, Italy ■ Tel +39 (06) 32 111 683 ■ Fax +39 (06) 32 656 990
Holzkirchen, DE ■ Ohmstrasse 3, 83607 Holzkirchen, Germany ■ Tel +49 (80 24) 47 00-0 ■ Fax +49 (80 24) 47 00-3 00
Hong Kong ■ Rm 1801, 18/F, Tower 1 Phase 1, Enterprise Square, 9 Sheung Yuet Road, Kowloon Bay, Kowloon, Hong Kong ■ Tel +852 2799 1220 ■ Fax +852 2799 9325
Service: (Americas) service@etconnect.com ■ (UK) service@etceurope.com ■ (DE) techserv-hoki@etconnect.com ■ (Asia) service@etcasia.com
Web: www.etconnect.com ■ Copyright © 2007 ETC. All Rights Reserved. ■ Product information and specifications subject to change.
7310M2210 ■ Rev A ■ Released 06/2007

ETC Setup Guide

Congo™ Light Server

Hardware Setup Connect Cables



- Step 1: Attach the appropriate IEC power cord to the power connector, then to the AC receptacle.
Step 2: Attach the dual DVI connector/Y-adaptor to the DVI port for digital video output.

Note: *The VGA connector on the rear panel of the unit is disabled. When using VGA monitors, connect the DVI (male) to VGA (female) adaptors (provided) to the DVI Y-adaptor (also provided and installed in step 2).*

- Step 3: Connect the USB mouse and keyboard to the USB connectors. To use a PS2 mouse and/or keyboard, you may use the serial connectors instead.
Step 4: Attach a network ethernet cable to the ethernet port.
Step 5: Connect optional cables as desired including remote trigger, midi, audio, printer and phone remote.
Step 6: When all connections are made, switch the mains power switch on.
Step 7: Press the soft power switch, on the front of the unit, to power up the light server.

Note: *If the unit does not power up, check the rear panel to insure the mains power switch is on.*


ETC Setup Guide

Congo™ Light Server


Connector Pinouts

DMX 512 connector pinout

Pin	Use
1	Common (shield)
2	Data -
3	Data +
4	no connection
5	no connection



Operation Overview



Backlit indicators identify the operating status of the light server.

LEDs indicate which mode the unit is operating (server, backup, client) and the status of the operation (master, backup sync or offline).

- The “Server” LED will illuminate when the unit is configured as a server.
- The “Backup” LED will illuminate when the unit is configured as backup and will blink when the unit has control of the lighting system. To control the output of data to the lighting system means the backup is now the master and the “Master” LED will illuminate as well.
- The “Client” LED will illuminate when the unit is configured as a client.
- The “Master” LED will illuminate when the unit is controlling the lighting system.
- The “Sync” LED will illuminate when the unit is synchronized with a server and will blink when the connection to the server has been lost.
- The “Offline” LED is illuminated when the unit is running offline.

20 command keypad buttons are configured for single Congo commands.

The 20 command buttons are set to default button assignments for optimal operation. Press and hold the **[Shift]** button to select the alternate function of any button (for example: **[Shift] [1]** to *Escape*).

USB port is provided for easy show loading to or from a USB storage device.

ETC Setup Guide

Congo™ Light Server

Rack Mounting Instructions

- Step 1: Locate the rack mounting kit including two rack mounting brackets and installation screws.
- Step 2: Align the mounting bracket to the appropriate side of the unit and secure it with the screws provided. Notice that the left and right side brackets are specific to the left and right sides of the unit.

