




CONGO™

Under the Hood.... Face panel PCB's




Congo Face Panel

To open the console, Pull front edge off table, until you see 2 black turn screws under the console. Turn them 1/4 turn Counter clockwise. You will need to use a US quarter, Euro, 100 Yen piece, Australian 10 cent piece, or standard screwdriver to open the console. Then lift up on BOTH sides of the console, not from the front.

THIS CONSOLE USES ALL METRIC SCREWS AND NUTS
Encoders 5.5mm nut driver.

Viewed as if looking into console.

Congo HWD REV B 9/6/05



Hard drives are keyed to the processors. Once they are initially booted in the Congo, the hard drive are keyed w/that specific console. Thus making it so hard drives cannot be swapped