

ETC[®] Service Note

Congo™ jr Face Panel Diagnostics





Tools Needed:

- DVI Monitor, or VGA w/ DVI adapters
- USB Keyboard
- USB Mouse

Procedure:

- Step 1: Connect all USB cables to the Congo jr USB ports
- Step 2: Turn on the console
- Step 3: At the main Congo screen press **[Ctrl]+[Alt]+[Delete]** from the USB Keyboard
- Step 4: Select **Task Manager**
- Step 5: Select the **Processes** Tab
- Step 6: Locate **"CongoShell"** Right click on it and click on **End Task**, then click **OK**
- Step 7: Locate **"Congo"** Right click on it and click on **End Task**, then click **OK**



Corporate Headquarters ■ 3031 Pleasant View Road, P.O. Box 620979, Middleton, Wisconsin 53562-0979 USA ■ Tel +608 831 4116 ■ Fax +608 836 1736
London, UK ■ Unit 26-28, Victoria Industrial Estate, Victoria Road, London W3 6UU, UK ■ Tel +44 (0)20 8896 1000 ■ Fax +44 (0)20 8896 2000
Rome, IT ■ Via Ennio Quirino Visconti, 11, 00193 Rome, Italy ■ Tel +39 (06) 32 111 683 ■ Fax +39 (06) 32 656 990
Holzkirchen, DE ■ Ohmstrasse 3, 83607 Holzkirchen, Germany ■ Tel +49 (80 24) 47 00-0 ■ Fax +49 (80 24) 47 00-3 00
Hong Kong ■ Room 1801, 18/F, Tower 1 Phase 1, Enterprise Square, 9 Sheung Yuet Road, Kowloon Bay, Kowloon, Hong Kong ■ Tel +852 2799 1220 ■ Fax +852 2799 9325
Service: (Americas) service@etcconnect.com ■ (UK) service@etc europe.com ■ (DE) techserv-hoki@etcconnect.com ■ (Asia) service@etcasia.com
Web: www.etcconnect.com ■ Copyright © 2006 ETC. All Rights Reserved. ■ Product information and specifications subject to change.
● Pending ■ Rev A ■ Released 02/2007

ETC Service Note


Congo™ jr Face Panel Diagnostics

Step 8: Select **File -> New Task (run)**

Step 9: Type **“cjtest.exe”** [ENTER]



Step 10: The following program will pop up:



Click here for face panel diagnostics


Click here for wing diagnostics

Step 11: Click on either the Congo jr Face button or the Congo jr Wing button.

ETC Service Note

Congo™ jr Face Panel Diagnostics


Step 12: The following window will pop up if you click the Congo jr Face button:



ETC Service Note

Congo™ jr Face Panel Diagnostics

Step 13: The following window will pop up if you click the Congo JR. Wing button:



Step 14: Move every slider and press every button on the face panel/master wing. Each button will change color to indicate that the hardware is functional.

Step 15: Every slider move will indicate a range from 0-255.

Step 16: When each button and slider tests out ok; close the window and power the Congo jr down.