



Eos Family v2.4 Facepanel Shortcuts

Displays

[Data] – a maintained press

Toggles the display to show data living under referenced data.
Keep Data depressed to page.

[Shift] + [Data]

Locks the display to the absolute data display

[Time] – maintained press

Toggles the display to show discrete timing.
Keep Time depressed to page.

[Shift] + [Time]

Locks the display to discrete time display.

[Data] + [Focus Encoder Page] / [Color Encoder Page] etc

To expand/suppress categories on displays (Ion)

[Data] + [Parameter Tiles]

To suppress/display individual parameters from the display when not in summary view (Ion)

[Params] + [Focus] / [Color] / [Beam]

To expand/suppress categories on displays (Ti/Eos/ Gio)

[Params] + [Parameter Tiles]

To suppress/display individual parameters from the display when not in summary view (Ti/Eos/Gio)

[Displays] + [Level Wheel]

Dim the Littlelites or backlighting/LCDs on Gio (as selected by the user). Browser button on Element

[Shift] + [Up], [Shift] + [Down], [Shift] + [Level Wheel]

Resize columns

[Shift] + [Path]/[Path]

Toggles the display to show values behind referenced data

[Shift] + [Tab]

Clear all tabs on the current monitor (but keep locked frames) (Does not clear tab 1 and 2)

[Shift] + [Tab] [Tab]

Clear all tabs on all monitors (but keep locked frames) (Does not clear tab 1 and 2)

[Shift] + [Tab] [Tab] [Tab]

Clear all tabs on all monitors (including locked frames) (does not clear tab 1 and 2)

[Shift] + [Label] – maintained press

Toggles the display between default view of referenced data and alternate view. Keep Shift depressed to page.

[Shift] + [Live/Blind]

Advances the displays to the next instance of live or blind

[Live] – when already in live

Resyncs the selected cue to the most recently activated cue

[Blind] – when already in blind

Resyncs the selected cue to the live selected cue (when blind cue has been changed or when preserve blind cue has been enabled).

[Flexi] + [Time]

To invoke flexi time view on displays

[Format] + [Level Wheel]

Zooms the display in focus

[Left Mouse Button] + Scroll

Zooms the display in focus on a PC

Scroll with two fingers

Zooms the display in focus on a Mac

[Tab] + [Up/Down Arrow]

Cycle workspaces

[Tab] + [Left/Right Arrow]

Move displays

[Tab] + [number]

Open or focus specific displays

Facepanel

[Shift] + [Escape]

To lock and unlock face panel

[Encoder Page Key] + [Number]

Pages to the desired encoder control page

[Escape] + [Encoder Page Keys]

Locks the encoders. Press any encoder page button to unlock.

[Flexi] + Encoder Paging key

To invoke flexi encoder states

[Fader Controls] + [Bump Button]

Select a fader page on wings

[Fader Page] + [Rate Wheel]

Rolls the selected fader page (Ti/Eos/Gio)

[Fader Page] + [number]

Select a fader page on integral faders and on wings (Ti/Eos/Gio)

[Fader Page]

Increments the fader page by 1 (Ti/Eos/Gio)

[Shift] + [Fader Page]

Decrements the fader page by 1 (Ti/Eos/Gio)

[Off] + [Load]

Releases control of content, restoring to background and leave cue list with pending cue in tact

[Release] + [Load]

Releases control of content, restoring to background, and resets cue list to top

[Shift] + [Go] or [Shift] + [Back]

Cuts the pending cue or the previous cue

[Shift] + [Load]

To remove content from a fader

[Escape] + [Load]

Releases the content on the specified fader and any other faders with that same content.



Eos Family v2.4 Facepanel Shortcuts

Operations

[At] [Enter]

Removes move information from selected channel/parameters.

[At] [At]

Set to Level

[Color] (Encoder page key) + [Encoder Movement]

Hold Color Point while adjusting parameters

[Copy To] [Copy to]

Posts Move To on the command line.

[Full] [Full]

Sets selected channels intensity to “full” and self terminates

[Go to Cue] [Shift] + [Home] [Enter]

Go to the last cue of the list.

[Label] [Label]

Appended to a record target command, clears the current label, this includes show file labels

[Recall From] [Recall From]

Posts Recall From Cue to the command line

[Record] [Record]

Posts Record Only to the command line.

[Select Active] [Select Active]

Select Active minus Submaster Contributions

[Shift] + [Select Active]

Posts Select Non-Sub Active

[Select Last]

Repeats last command line, unterminated; does a loop of last five commands

[Shift] + [At]

Recalls last channel(s) and parameters without terminating; does a loop of last five commands

[Shift] + [Enter]

Reselects the last command and leaves it unterminated; does a loop of last five commands

[Shift] + [Block]

Posts Intensity Block to the command line

[Shift] + [Clear]

Clears the command line

[Shift] + [Delay]

Posts follow

[Shift] + [Delay] [Delay]

Posts hang to the command line

[Shift] + [Encoder Page Key]

Posts the category to the command line. For beam subcategories, press Image, Form or Shutter twice to post Beam. (Ion/Gio)

[Shift] + [Encoder Movement]

Accesses fine mode

[Shift] + [Encoder Toggle]

Posts the parameter to the command line

[Shift] + Gel Tile

Cycles through three modes of Brightness

[Shift] + [Full] or [Shift] + [Out]

Flash On or Flash Out

[Shift] + [+] or [Shift] + [-]

+% or -%

[Shift] + [Highlight]

Appends highlight to the current channel selection.

[Shift] + [Parameter]

From the encoder controls, posts the parameter to the command line.

[Shift] + [Select Last]

Posts additional channel selection options to the softkeys

[Shift] + [Sneak]

Makes manual data “unmanual”.

[Shift] + [Update]

Shortcut to “Save”

[Shift] + restore manual channel faders.

Reset faders to zero without asserting control.

[Shift] + [Direct Select]

Posts DS to the command line without terminating

[Sneak] [Sneak]

Releases NPs of selected channels and self terminates

[Timing Disable] + [Go] or + [Back]

Cuts the next cue or cuts the last cue

[Thru] [Thru]

[Thru] command accesses only channels displayed in the current flexi-state (unless the range specified is NOT in the current display).
[Thru] [Thru] selects the range regardless of the flexi mode.

[Trace] [Trace]

Forces a previously inactive light to track its new intensity setting backwards

[Undo]

Clears an unterminated command line. Otherwise opens undo controls

[Update] + [Sub Bump]

To update a specific submaster

[n] [At] [/] [/] [m] [Enter]

Sets direct DMX value (m) for channel (n).