

Consoles 121

Setting up Emphasis System Components

Setting System ID

This must be changed in 2 places and then the Emphasis Application as a whole needs to be shut down and rebooted.

- Login
- Launch Emphasis
- Minimize Application
- Performed in Emphasis Console Application
 - Go to Task Bar at bottom of Screen
 - Right Click on Emphasis Console Tab
 - Select Restore
 - Select Options from the bar that contains File, Options, Window, and Help
 - Select System ID
 - Set System ID number in the System box
 - The Name box is the Label that appears on the facepanel Login Screen
 - Select OK
 - Minimize Console application
- Performed in Emphasis Visualization Application
 - Restore Emphasis Visualization
 - Go to the Emphasis Mode
 - Select Options from the bar that contains File, Edit, Library, etc.
 - Select Application Options
 - Click the Emphasis Tab
 - Set the SAME System ID that you set in Console Application
 - Select OK
- Logout
- Login as Emphasis User
- Reboot facepanel

Setting Facepanel Type

- Any login has permission to change this setting
- Go to Visualization Emphasis Mode
- Click on Setup
- Click on Facepanel Type
- Choose the facepanel that will be connected to the system
- Click OK
- Close and relaunch Emphasis for the changes to take effect
 - This setting will affect the CRT displays of all facepanels connected to the system.*

Setting Password for System Manager

- Login as System Manager
- Go to Start Button
- Select All Programs
- Select User Accounts
- Click Create a Password
- Type in password in appropriate spaces
- Type hint. This hint will appear when you press the question mark by the login.
- Click Create Password

This password will be required the next time you login as system manager.

Removing System Manager Password: If known

- Log in as system manager with password
- Go to Start
- Select All Programs
- Select User Accounts
- Click Remove my password
- Type password in the box
- Click Remove Password

If you don't know what the password is, a technician can remove it using the Technical Service log in. An enduser would need to reload the disk image in order to remove the password.

Changing or Removing System manager Password: Technician only

- Log is as Technical Service
- Go to Start
- Select Control Panel
- Select User Accounts
- Select System Manager
- Follow prompts on screen

**Please do not modify other accounts because it make the system very hard to troubleshoot.
NEVER change the technical service password.**