

ETC Release Note

Source Four LED Series 3 Fixture Software

Product Line:

Source Four LED Series 3 Fixture Software

Description:

Version 1.3.0 System Software

Fixture Software Components

Source Four LED Series 3 Fixture Software	1.3.0.18
Array	1.1.0.10 or 2.1.0.10 or 3.0.0.3 LPC
DIM	F00C or CPU PWM

Effective Date:

2023-11-27

Purpose

This release adds a new HSIC DMX mode and a new Quick dimming curve.

For any questions relating to the contents of this release or the behavior of this software, please contact ETC Technical Services at the office nearest you (visit etcconnect.com/contactETC).

Availability

This software is currently available in shipping units.

Documentation

Current documentation includes:

- *Source Four LED Series 3 User Manual*
- *Source Four LED Series 3 Quick Guide*

ETC manuals in portable document format (pdf) are available for download at etcconnect.com.

Compatibility

This release is compatible with the following ETC hardware:

- Source Four LED Series 3 fixtures

Key Enhancements in v1.3.0

- Adding HSIC DMX mode
- Adding Quick dimming curve

Key Enhancements in v1.2.0

- Adding stand-alone Gel mode
- Multiverse enhancements, including wireless strength and quality display
- Direct mode is now the default DMX mode
- **Function** button now displays a list of modes to choose from, rather than requiring you to toggle through the mode screens individually
- Control priority for the fixture now follows a "last takes precedence" rule, with wired DMX taking precedence over wireless DMX when both are present



Corporate Headquarters ■ Middleton, WI, USA | +1 608 831 4116
Global Offices ■ London, UK | Rome, IT | Holzkirchen, DE | Paris, FR | Hong Kong | Dubai, UAE | Singapore
New York, NY | Orlando, FL | Los Angeles, CA | Austin, TX | © 2024 Electronic Theatre Controls, Inc.
Web etcconnect.com | Support support.etcconnect.com | Contact etcconnect.com/contactETC
Trademark and patent info: etcconnect.com/ip | Third-party license agreement info: etcconnect.com/licenses
Product information and specifications subject to change. ETC intends this document to be provided in its entirety.
7462M1100-1.3.0 Rev B Released 2024-10

ETC Release Note

Fixture Software v1.3.0

Key Enhancements in v1.1.0

- Bug fix in dimming engine
- Updates to Direct mode calibration data

Key Enhancements in v1.0.0

- Initial release of v1.0.0 fixture software

Installation Instructions

All Source Four LED Series 3 fixtures ship with the current version of software and do not require an update before use. To update existing fixtures, follow the instructions below.

Update Firmware

When fixtures are connected to data, you can update firmware directly using UpdaterAtor. For information on UpdaterAtor, see the *UpdaterAtor Software Quick Guide* and the *UpdaterAtor Software Release Note*, which you can download from etcconnect.com.

You can also update firmware using a USB drive. After you update a single fixture using a USB drive, you can update all fixtures that are connected via wired DMX from that fixture.

Update a Single Fixture Using a USB drive

1. Visit etcconnect.com or use UpdaterAtor to get the updated firmware file for the fixture, and then save the firmware file to a USB drive. For information on UpdaterAtor, see the *UpdaterAtor Software Quick Guide* and the *UpdaterAtor Software Release Note*, which you can download from etcconnect.com.
2. Insert the USB drive in the USB port on the rear of the fixture.
3. Press the **Menu** button (⌂), and then use the Intensity encoder to navigate through the menu: **Local Settings > USB > Update Firmware**.
4. Use the Intensity encoder to navigate to the firmware update file, and then press the Intensity encoder to begin the firmware update. The firmware update includes several steps:
 - a. Copying the files to the fixture: A progress meter displays as the files are copied to the fixture.
 - b. Verifying the files: The ETC logo displays on the top half of the screen as the fixture verifies the files. You can safely remove the USB drive at this time.
 - c. Updating the fixture: The fixture installs the updated firmware files.

Update All Connected Fixtures

1. After you update the firmware on a fixture, verify that the fixture is not receiving DMX/RDM before you proceed.
2. Press the **Menu** button (⌂) on the fixture, and then use the Intensity encoder to navigate through the menu: **Local Settings > Push Firmware**.
3. When the screen prompts you to confirm, press the green encoder (for the **OK** icon ✓) to continue. The updated firmware is copied to all connected fixtures, and the screens on connected fixtures display a progress message ("Firmware RX x%").

ETC Release Note

Fixture Software v1.3.0

Known Issues Remaining in v1.3.0

- S4LED3SW-297 When the fixture is in a standalone mode and DMX is present when it is powered on, any configuration changes made via NFC when the fixture was powered off are lost.
Workaround: Apply DMX only after the fixture is powered on.
- S4LED3SW-253 Strobe gets out of sync on multiple fixtures.
- S4LED3SW-251 In the **Preset Mode** screen, capturing the current DMX look to a preset (using the **Snapshot** icon) does not work.
Workaround: Modify the preset using the fixture user interface or via RDM instead.
- S4LED3SW-187 When connected fixtures are all playing the same color in stand-alone Color mode, rapid adjustments in the **Color** screen on one fixture can cause the other connected fixtures to no longer play the same color as the changed fixture.
Workaround: Wait a moment, and then make the adjustment in the **Color** screen again. The connected fixtures will receive the changes in color if you make them more slowly.
- S4LED3SW-178 When playing a preset, the gamut indicator on the user interface and the **About Color** screen (**Diagnostics > About Color**) do not display correct values.
- S4LED3SW-150 Making changes on the fixture user interface during a firmware update causes the firmware update to fail.
Workaround: After you begin a firmware update, do not interact with the fixture user interface until the firmware update is complete.
- S4LED3SW-137 Firmware update fails when the fixture is playing a sequence.
Workaround: Stop sequence playback before updating firmware.
- S4LED3SW-118 In the **Color** screen, it is possible to select a color in the **Hue/Saturation** color selection mode that will result in the crosshairs being outside of the chromaticity diagram in the **x,y** color selection mode.
Workaround: Change back to **Hue/Saturation** color selection mode to make additional adjustments.
- S4LED3SW-114 With the fixture in **Expanded** mode, and the **Mix** channel set to 255 (Full RGB), the **CCT** channel should remain at 3200 K, but instead can be adjusted.
- S4LED3SW-113 Metamer control has no effect near the edge of the gamut.
- S4LED3SW-64 The fixture does not report over-temperature errors over RDM.